


# machines/设备

bale opener/开包机

process flow/工艺流程



THE MATERIAL, USUALLY AVAILABLE AS PRESSED BALES (01), IS TRANSFERRED BY THE FEEDING BELT (02) TO THE INCLINED SPIKED BELT (03). THE CONICAL PINS OF THE BELT OPEN THE FIBRES AND TAKE THEM TO THE DISCHARGING ROLLER (05). THE DOSING ROLLER (04) PLAYS A CRUCIAL ROLE DURING THE FIBRE FEEDING SO THAT TO GUARANTEE A PERFECT CONTROL OF THE MATERIAL DISCHARGED INTO THE WEIGHING PAN (06)

喂料平帘(02)将通常是压实包装的原料(01)输送至喂料角钉斜帘(03),斜帘上锥形圆钉对原料进行开松并转移给卸料罗拉(05)。在喂料过程中,匀料辊(04)起了关键作用,其使喂入称重料斗(06)的原料供量稳定